

安全注意事项

非常感谢您购买本产品。

本文记载了有关安全使用本产品的重要信息。使用本产品前，请务必仔细阅读本注意事项和使用说明书，正确和安全地使用本产品。并且，请妥善保管本注意事项，以便在使用本产品时可以随时查看本注意事项。

关于高安全性用途的使用 <p>本产品适用于普通事务、个人、家庭、普通的产业等普通的用途，不适用于原子能设施中的核反应控制、飞机自动飞行控制、航空交通管制、大量运输系统中的运行控制、维持生命的医疗器械、武器系统中的导弹发射控制等，对安全性要求极高的，一旦该安全性得不到保证，直接对生命或身体有重大危害的用途（以下称“高安全性用途”）。使用者在未采取措施，确保该高安全性用途所需的安全性之前，请勿使用本产品。使用者将本产品用于高安全性用途后发生损害时，对使用者或第三方的要求或损害赔偿，本公司概不负责。</p>
--

Bluetooth为Bluetooth SIG, Inc.的注册商标。其他公司名称和产品名称均为各自公司的注册商标或商标。

© PFU Limited 2019-2023

2023年6月

警告标识

本注意事项，是为了让使用者安全、正确地使用本产品，事先防止对使用者或其他人可能造成的危害和损害的发生，具体标识如下：

	警告标识	说明
	危险	这个标识表示如果不正确使用本产品，将有死亡或重伤的危险。
	警告	这个标识表示如果不正确使用本产品，将有死亡或重伤的可能。
	注意	这个标识表示如果不正确使用本产品，可能导致轻伤或财产损失。
		用三角表示的标识是指警告、提醒注意的事项。标识中包含具体的警告内容图示。
		圆圈里有斜线的标识用于告知此行为是禁止行为。在标识中或者标识周围可能会有具体的指示内容图示。
		黑色圆圈中有白色惊叹号的标识用于告知必须遵守的内容。标识中可能包含具体的指示内容图示。

为了安全使用本产品

有关本产品的重要警告事项如下。

为了安全使用本产品，请必须遵守以下记载事项。

	危险	
		避免水、海水、饮料等液体弄湿键盘。否则，可能导致电池发热、破裂或起火。
		请勿在高温场所（靠近火或取暖设备的场所、阳光直射的场所、炎热天的汽车内）及低温场所，或高海拔、低气压的场所对键盘及电池进行使用、充电、存放和放置。否则，可能导致电池漏液、发热、破裂或起火。

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----

	请勿点燃键盘及电池，或将其扔到火中。否则，可能导致电池发热、破裂或起火。
	请勿将钉子打入键盘及电池中，或用锤子敲打；请勿踩踏键盘及电池、使其遭受强烈撞击，或用机器进行挤压和切割。否则，可能导致电池发热、破裂或起火。
	请勿放入微波炉等烹饪加热设备和高压容器，或放置于电磁炉（IH电磁炉）上。否则，可能导致电池发热、破裂或起火。
	请勿使用可能导致保护功能失效的型号错误的电池（如个别类型的锂电池）。否则，可能导致电池发热、破裂或起火。
	如果电池漏液，请避免沾到脸部和手部。否则，可能导致失明或伤害皮肤。万一液体等进入眼睛、嘴巴，或附着到皮肤、衣服上，请立即用清水冲洗。此外，如果进入眼睛、嘴巴，请在清洗后立即接受医生的诊断。

	警告	
		如果发生以下情况，请立即关掉电源，并停止使用。确认无电池发热等异常情况后，在注意避免烫伤的同时，将其从键盘中取出。如果键盘上连接有线缆，请将其拔下。 <ul style="list-style-type: none">键盘掉落 键盘冒烟，键盘外侧异常发热。 键盘发出异常声音、异常臭味。 有异物（例如水、咖啡等液体、回纹针等金属片）进入键盘内部。 其他感到可疑的情况。
		如果电池漏液或发出异味，请立即停止使用，并使其远离烟火等引火危险物。否则，可能导致电池破裂、起火。
		请勿拆解或改装键盘。此外，如果您自行拆解键盘，我们将不再负责键盘的保修。对拆解键盘所引起的任何损失，本公司也一概不负责。
		本键盘仅限在中国使用。请不要在中国以外的地区使用。
		请勿将键盘放置于如下所述的高温、湿度大的场所和换气性差而多尘的场所。高温会导致键盘发生过热、变形、溶解等情况，从而引发漏电和火灾。因此，请在通风和换气性良好的地方使用本产品。 <ul style="list-style-type: none">靠近暖炉和加热器等加热设备的场所、或靠近挥发性可燃物和窗帘等易燃物品的场所 厨房等产生油烟的场所 浴室、淋浴房、泳池等潮湿场所 阳光直射的场所、炎热天的汽车内、取暖设备附近等高温场所
		请注意本产品及其周边设备的布线。否则，可能被线缆绊到脚而摔倒，或导致本产品及周边设备掉落、翻倒，而造成人员受伤或设备故障。此外，请勿让儿童轻易地触碰到线缆。如果误缠绕到脖子上，可能导致窒息。
		如要移动键盘，请拔下连接在键盘上的线缆。此外，在作业中请注意充分注意脚下安全。如果在连接着线缆的状态下移动键盘，可能导致线缆受损，或造成火灾、触电、人员受伤。
		在驾驶汽车过程中，请勿使用键盘。否则，可能影响安全驾驶，而引起交通事故。
		在清洁键盘时，请勿使用空气喷雾器或含有酒精的喷雾器。从喷雾器喷出的强力气体可能将灰尘等异物吹入键盘中，从而导致键盘故障或工作异常。此外，静电等可能会产生火花，而引发火灾。
		在禁止使用电波的场所（医疗设施等），请遵守该场所的规定。否则，可能影响电子设备、医疗设备和植入性医疗器械（心脏起搏器等）。这是利用电波的机器的一般特性，并非键盘独有的特性。

	注意	
		请避免键盘的任意部分从桌子的范围突出。此外，请将键盘放置在振动少而平坦的地方，以防止键盘倾斜。否则，键盘可能掉落或翻到，从而导致人员受伤。
		请勿放置在儿童伸手可及的场所。否则，可能导致受伤。
		请勿在键盘放置重物，或在键盘上进行作业。否则，可能导致故障或人员受伤。
		请确保本产品远离强大磁场和干扰发生源。此外，请选择不易产生静电的材质地板材料和桌子，以放置本产品。否则，静电可能导致键盘发生误动作。
		建议尽可能将键盘和电脑或移动设备放置在视野宽阔的场所。如果有阻挡电波的障碍物（墙壁和金属板等），可能无法通信或导致通信速度变慢。
		从寒冷的房间突然移动到温暖的房间时，键盘会发生结露。如果继续使用，有可能会发生键盘输入不正常的问题。请在温暖的房间放置1到2个小时，待内部干燥后再使用。
		在下雨天和下雪天，如要将键盘带到室外，请注意不要弄湿键盘。万一弄湿了键盘，请将其擦干或放置一段时间，待其干燥后再使用。

使用上的注意点

■ 责任说明

对于本产品所提供的使用说明书和键盘的使用，由客户自行负责。对于因使用本产品而造成的损害和数据损失，我公司不承担任何责任。此外，无论在任何情况下，本产品的保修金额不超过客户所支付的购买本产品的金额。敬请理解。

■ 电池的使用

- 请存放在儿童伸手不及的场所。
- 请勿颠倒电池的正极（+）和负极（-）以进行使用。
- 请勿对电池加热。此外，请勿拆解或放入水中。
- 如果长期使用本产品，请取出电池。否则，可能发生漏液或故障。
- 请勿组合使用旧电池和新电池。此外，请勿组合使用不同类型的电池（锰电池和碱性电池等）。
- 请停止使用电力变弱的旧电池，并根据所在地区的条例及法令进行处理。

■ 蓝牙通信速度

登载的通信速度为根据标准所使用的通信速度，并不表示实际的通信速度。实际的通信速度因客户使用键盘的环境而异。

- 此外，如果在以下环境中使用，可能无法通信或导致通信速度变慢。
 - 键盘距离电脑或移动设备过远。
 - 在生产电波干扰的设备（微波炉等）附近使用键盘。

各种标准

《电波法》
本产品装载了根据销售地区的法令、规则设计的无线功能。请勿擅自拆解本产品，或改装内部的电路等。否则，根据销售地区的法令、规则，顾客可能受到处罚。此外，因为拆解和改装而造成的损害，本公司不承担任何责任。

维护

请不要不要自行对键盘进行修理。如果您自行拆解键盘，我们将不再负责键盘的保修。对拆解键盘所引起的任何损失，本公司也一概不负责。如果需要修理，请联系提供键盘的经销商或分销商。详情请参照“故障、修理等咨询”。

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----

循环再利用

■ 对使用过的产品的报废和重新利用的呼吁

- 个人购买的客户如要报废本产品（包含附属品），请根据地方行政机关所发布的相关条例进行妥善的处理。
 - 法人、企业等客户如要报废本产品（包含附属品），请将其作为工业废物进行妥善处理。

故障、修理等咨询

本公司为了让使用者放心使用键盘，建立了完善的支持体制。通过在客户需要时，随时提供精准化服务，给予使用者强有力的支持。

返回和良品更换	良品更换费用（实际费用）运费：发送方承担
保修和售后服务的联系方式 <p>https://happyhackingkb.com/</p>	
关于详细信息，请浏览以上网站。	
重要	<ul style="list-style-type: none">请顾客不要自行对本产品进行修理。 关于本产品的保修条件，请查看本书中保修卡的规定。 本产品的有效支持期限为停止生产后的5年内。

注意：

- 未经我公司许可，不得转载本文的内容。

Safety Precautions

Thank you for purchasing this product.

This document contains the general information for safety that must be read before using this product. Read this document and the Users Guide and take care to use this product safely and correctly. Make sure that these are kept in a safe place so that they can be referred to whenever using this product.

Use in High-Safety Applications <p>This product has been designed and manufactured on the assumption that it will be used in office, personal, domestic, regular industrial, and general-purpose applications. It has not been designed and manufactured for use in applications (simply called "high-safety applications" from here on) that directly involve danger to life and health when a high degree of safety is required, for example, in the control of nuclear reactions at nuclear power facilities, automatic flight control of aircraft, air traffic control, operation control in mass-transport systems, medical equipment for sustaining life, and missile firing control in weapons systems, and when provisionally the safety in question is not ensured. The user should use this product with adopting measures for ensuring safety in such high-safety applications. PFU Limited assumes no liability whatsoever for damages arising from use of this product by the user in high-safety applications, and for any claims or compensation for damages by the user or a third party.</p>
--

Bluetooth is a registered trademark of Bluetooth SIG, Inc.

Other company names and product names are the registered trademarks or trademarks of the respective companies.

© PFU Limited 2019-2023

June 2023

Warning Indications Used in This Document

The following indications are used in this document to obviate any chance of accident or damage to you and/or this product.

Warning Indication	Description
	This indication alerts operators of an operation that, if not strictly observed, may lead to the risk of causing severe injury or death.
	This indication alerts operators of an operation that, if not strictly observed, may result in severe injury or death.
	This indication alerts operators of an operation that, if not strictly observed, may result in safety hazards to personnel or damage to the product.
	A TRIANGLE symbol indicates that special care and attention is required. The drawing inside the triangle shows the specific caution.
	A CIRCLE with a diagonal line inside shows actions which users should not perform. It may also have a drawing inside which shows the specific action that is not allowed.
	A white exclamation mark on black background shows instructions users should follow. It may also include the drawing that shows the specific instruction.

For Safe Use

The following describes important warnings for using this product.

For the safe use of this product, make sure to follow the following descriptions.

	DANGER	
		Do not get the keyboard wet with water, seawater, beverages, or any other liquids. Doing so may cause the batteries to heat up, explode, or ignite.

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----

	Do not use, store, or leave the keyboard or batteries in any location subject to high temperature (such as in a place located by a fire or a heater, in direct sunlight, or inside a car under the blazing sunlight), in any location subject to low temperature, or in any high-altitude location with low air pressure. Doing so may cause the batteries to leak, heat up, explode, or ignite.
	Do not burn the keyboard or batteries, or do not throw them into fire for any reason. Doing so may cause the batteries to heat up, explode, or ignite.
	Do not strike a nail into the keyboard or batteries, hit them with a hammer, step on them, treat them badly causing high levels of impact, or crush or cut them by using a machine. Doing so may cause the batteries to heat up, explode, or ignite.
	For any reason, do not place the keyboard in a cooking appliance (such as a microwave oven), in a high-pressure container, or on an electromagnetic cooker (such as an induction heating cooker). Doing so may cause the batteries to heat up, explode, or ignite.
	Do not use an incorrect type of battery that may disable the protection function (for example, some types of lithium batteries). Doing so may cause the batteries to heat up, explode, or ignite.
	If battery leakage occurs, keep the liquid away from your face or hands. Not doing so may cause blindness or skin damage. If the liquid gets into your eyes or mouth, or gets on to your skin or clothes, rinse with clean water immediately. Also, in the case that the liquid gets into your eyes or mouth, go to the hospital.

	WARNING	
		If any one of the situations below happens, turn the power off and stop using it. Make sure that the batteries do not have any problems, such as being too hot, and be careful not to burn yourself when taking them out of the keyboard. If a cable is used, disconnect the cable from the keyboard. Not doing so may result in a fire or an electric shock. <ul style="list-style-type: none">The keyboard has been dropped. Smoke or heat coming from the keyboard is detected. Abnormal noise or smell is detected. Foreign objects (water, liquids, small metal objects, etc.) get inside the keyboard. Other problems which indicate a keyboard failure are detected.
		If battery leakage occurs or an abnormal smell is detected, stop using the keyboard. If it is placed near a fire, move it away from the fire. Not doing so may cause the battery to explode or ignite.
		Do not take apart or modify the keyboard. In addition, taking apart the keyboard by yourself voids the warranty. PFU is not responsible for any damages or losses resulting from taking the keyboard apart by yourself.
		Do not place the keyboard in locations which are subject to high temperatures, humidity, poor ventilation, or dust. If placed in an area subject to high temperatures, the frame may become overheated and deformed, resulting in an electrical leakage or fire. Use the keyboard in a well-ventilated environment. For example, do not place the keyboard in the following locations: <ul style="list-style-type: none">A place near heat-radiating devices such as stoves or electric heaters, or flammable items such as volatile inflammable materials or curtain. A place such as kitchen where oil smoke may be formed. A place such as a bathroom, shower room, or swimming pool where it may easily get wet. A place under direct sunlight, in a car under the scorching sun, or near heating apparatus where it may get hot.
		Wire the cables for this product as well as other peripheral devices carefully. If your foot gets caught in one of the cables, you may trip over or the product as well as other peripheral devices may fall over or be pulled off from high places, causing injuries or an equipment failure. To prevent children from choking by getting the cables caught around their neck, wire the cables so that children cannot reach them easily.

	Before moving the keyboard, be sure to disconnect the cable of the keyboard from the computer. Make sure that the floor is free of any obstructions. Do not move the keyboard with the cables connected as this can damage the cables, which can later cause a fire or electric shock. The cables can also hinder work, causing injuries.
	Do not use the keyboard while driving a car. Doing so may prevent you from driving carefully, which can cause an accident.
	Do not use any aerosol sprays or alcohol based sprays to clean the keyboard. Dust blown up by strong air from the spray may enter the inside of the keyboard. This may cause the keyboard to fail or malfunction. Sparks, caused by static electricity, generated when blowing off dust and dirt from the outside of the keyboard may cause a fire.
	In areas (such as hospitals) where the use of radio waves is restricted, do not use the keyboard in accordance with the instructions in the area. There is a possibility that the radio waves may affect electronic devices, medical devices, and implanted medical devices (such as cardiac pacemakers). This is a general characteristic of all devices that use radio waves, and is not specific to this keyboard.

	CAUTION	
		When placing the keyboard on a table, make sure that the work surface is flat and stable, and that none of the keyboard's parts extend over the table edge, otherwise it may fall over or be pulled off the table and cause injuries or damage.
		To avoid injuries, do not place the keyboard in an area where small children may be able to reach.
		Do not place heavy objects on the keyboard or perform other work on top of the keyboard. Doing so might cause injuries or an equipment failure.
		Place the keyboard away from strong magnetic fields and other sources of electronic noise. Protect the keyboard against any static electricity and choose a static-free place to place the keyboard. Static electricity can cause the keyboard to malfunction.
		It is recommended that you place the keyboard and a computer/mobile device in the most open place possible. If there are obstacles (such as walls or metal plates) that block the radio waves, data transmission may not be possible, or the transmission speed may slow down.
		Do not use the keyboard immediately after moving it from a cold place into a warm room. Condensation may occur, which might lead to input errors. Let the keyboard dry for one or two hours before using it.
		When carrying the keyboard outside while it is raining or snowing, pay special attention so the keyboard does not get wet. If the keyboard gets wet, wipe it or wait until it dries.

Precautions

■ Liability Note

READ THE DOCUMENTS SUPPLIED WITH THIS PRODUCT CAREFULLY BEFORE USING THIS KEYBOARD. IF THIS KEYBOARD IS NOT USED CORRECTLY, UNEXPECTED INJURY MAY BE CAUSED TO USERS OR BYSTANDERS.

Also, keep this document in a safe place so that it can be easily referred to during use of this keyboard. While all efforts have been made to ensure the accuracy of all information in this document, PFU assumes no liability to any party for any damage caused by errors or omissions or by statements of any kind in this document, its updates or supplements, whether such errors are omissions or statements resulting from negligence, accidents, or any other cause. PFU further assumes no liability arising from the application or use of any keyboard or system described herein, nor any liability for incidental or consequential damages arising from the use of this document. PFU disclaims all warranties regarding the information contained herein, whether expressed, implied, or statutory.

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	--