
ScanSnap Online Update V2.0L60 README File

- Contents -

1. Cautions for using environment-dependent characters
2. Cautions Concerning Installation
3. Cautions Concerning the Operation
4. Cautions Concerning Uninstallation
5. Updated features

Use in High-Safety Applications

This product has been designed and manufactured on the assumption that it will be used in office, personal, domestic, regular industrial, and general-purpose applications. It has not been designed and manufactured for use in applications (simply called "high-safety applications" from here on) that directly involve danger to life and health when a high degree of safety is required, for example, in the control of nuclear reactions at nuclear power facilities, automatic flight control of aircraft, air traffic control, operation control in mass-transport systems, medical equipment for sustaining life, and missile firing control in weapons systems, and when provisionally the safety in question is not ensured.

The user should use this product with adopting measures for ensuring safety in such high-safety applications. PFU LIMITED assumes no liability whatsoever for damages arising from use of this product by the user in high-safety applications, and for any claims or compensation for damages by the user or a third party.

1. Cautions for using environment-dependent characters

- o ScanSnap Online Update does not support environment-dependent characters (unicode). Do not use environment-dependent characters (unicode) for the following:
 - the folder name for installing ScanSnap Online Update
 - the user name when using ScanSnap Online Update
 - characters including the names of folders and files handled in ScanSnap Online Update

2. Cautions Concerning Installation

- o For details about supported operating systems, refer to "System Requirements" in the Operator's Guide or Basic Operation Guide of your ScanSnap model.
- o When installing ScanSnap Online Update on Windows(R), first log on as a user with administrator privileges, and then install ScanSnap Online Update.
- o ScanSnap Online Update may not function properly if the path for the installation folder exceeds 100 characters.
When installing ScanSnap Online Update, specify a path within 100 characters.
- o If the User Account Control dialog box appears, allow the installation to proceed.
- o Do not use any of the following characters for the name of the installation folder. ScanSnap Online Update may not function properly if these characters are used.

/ ; , . * ? " < > | # %
- o Specify a folder on a local disk as the installation folder.

3. Cautions Concerning the Operation

- o Operations using Terminal Service Client or Remote Desktop Connection Client services or those on a virtual OS are not guaranteed.
- o Depending on the User Account Control setting status, ScanSnap software may not be updated or installed. Selecting "Default" in the User Account Control settings is recommended.

4. Cautions Concerning Uninstallation

- o Uninstallation of ScanSnap Online Update will be executed after all the ScanSnap software have been uninstalled.
To uninstall, use [Uninstall a program] ([Add or Remove Programs] in Windows(R) XP) in the Control Panel.
- o When uninstalling ScanSnap Online Update, first log on as a user with administrator privileges.
- o If the [User Account Control] dialog box appears, allow the uninstallation to proceed.
- o If the file to be uninstalled is in use while you are trying to uninstall this application, log on as a user with administrator privileges once after restarting your computer. This completes the uninstallation.

5. Updated features

- o Changes from V2.0L50 to V2.0L60
 - OCR Pack distribution is now supported.
- o Changes from V2.0L40 / V2.0L41 to V2.0L50
 - A modification has been made so that multiple update programs for one software program can be applied at a time.
 - A modification has been made so that the latest update for this product is prompted to apply.
 - Modified the error of the automatic online update regarding daylight saving time.
 - A modification has been made to avoid the error that a response may not be received from the online update depending on the User Account Control settings.
 - The icon designs have been changed.
- o Changes from V2.0L30 to V2.0L40
 - A new option has been added to notify information about ScanSnap.
 - The start time for automatic online update has been changed from "on the hour (0 minutes)" to the one-hour period (between 0 and 59 minutes) following the hour you specify.
- o Changes from V2.0L15 to V2.0L30
 - The ScanSnap Improvement Program (*) has been added.
*: The program helps to improve ScanSnap by collecting anonymous data from ScanSnap.
The collected data do not contain any personal data.
- o Changes from V2.0L14 to V2.0L15
 - A modification has been made so the new software that has not been

installed is notified by the automatic online update only when it becomes available.

o Changes from V2.0L13 to V2.0L14

- A modification has been made so you can specify in the settings window to skip the checking for available updates of your desired software.

o Changes from V2.0L12 to V2.0L13

- Fixed the error where either the layout collapses or some literals do not fit in their fields in the settings window when [Medium - 125%] is selected in [Control Panel]-[Appearance and Personalization]-[Display]. The actual windows and operations may differ depending on the operating system.

o Changes from V2.0L10 to V2.0L12

- Fixed the error where some window literals do not fit in their fields when [Medium - 125%] is selected in [Control Panel]-[Appearance and Personalization]-[Display]. The actual windows and operations may differ depending on the operating system.

o Changes from V1.0L50 to V2.0L10

- A new feature has been added to check ScanSnap-related software available online, and install them newly.
- Modified the error where old update information appears in the updates list when you double-click the "new updates available" alert on the taskbar notification area after leaving it unchecked for a long time.

o Changes from V1.0L40 to V1.0L50

- A modification has been made so that the summary of updates appears immediately after the updates list is displayed.
- Modified the garbled text in screens and messages in German OS.

o Changes from V1.0L30 to V1.0L40

- Minor errors have been modified.

o Changes from V1.0L20 to V1.0L30

- Modified the error where runtime error may occur.

o Changes from V1.0L11 to V1.0L20

- Modified the error where the registered program is indicated as unknown in the [User Account Control] dialog box.

o Changes from V1.0L10 to V1.0L11

- Modified the German notification for available updates.

=====
Microsoft, Windows, and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

ScanSnap is a registered trademark of PFU LIMITED in Japan.

Other company names and product names are the trademarks or registered trademarks of the respective companies.

Copyright PFU LIMITED 2012-2016