
Fujitsu ScandAll PRO V2.0.15
README

Copyright PFU LIMITED 2007-2014

This file contains information about things you should know before using this product as well as the latest information, which is not included in Online Help topics.
Be sure to read this file prior to use.

* Use in High Safety Applications

This Product is designed, developed and manufactured as contemplated for general use, including without limitation, general office use, personal use, household use, and ordinary industrial use, but is not designed, developed and manufactured as contemplated for use accompanying fatal risks or dangers that, unless extremely high safety is secured, could lead directly to death, personal injury, severe physical damage or other loss (hereinafter "High Safety Required Use"), including without limitation, nuclear power reactioncore control in nuclearatomic facility, airplane automaticaircraft flight control, air traffic control, operation control in mass transport controlsystem, medical instrument for life support system, missile launching control in weapon system.

You shall not use this Product without securing the sufficient safety required for the High Safety Required Use.

In addition, PFU (or other affiliated company) shall not be liable against the Customer and/or any third party for any claims or damages arising in connection with the High Safety Required Use of the Product.

[Table of Contents]

1. System Requirements
2. Installation
3. Uninstallation
4. Notes

1. System Requirements

1) CPU

Intel(R) Core(TM)2 Duo 2.2 GHz or higher recommended

- For more information about how to connect to the computer and other requirements, refer to the manual that comes with your scanner.

2) Operating Systems

OS that supports ScandAll PRO

- Windows(R) XP Home Edition (SP3 or later)
- Windows(R) XP Professional (SP3 or later)
- Windows(R) XP Professional x64 Edition (SP2 or later)

- Windows Server(TM) 2003 R2, Standard Edition (SP2 or later)
- Windows Server(TM) 2003 R2, Standard x64 Edition (SP2 or later)
- Windows Vista(TM) Home Basic (32/64bit) (SP1 or later)
- Windows Vista(TM) Home Premium (32/64bit) (SP1 or later)
- Windows Vista(TM) Business (32/64bit) (SP1 or later)
- Windows Vista(TM) Enterprise (32/64bit) (SP1 or later)
- Windows Vista(TM) Ultimate (32/64bit) (SP1 or later)
- Windows Server(TM) 2008 Standard (32/64bit)
- Windows Server(TM) 2008 R2 Standard (64bit)
- Windows(R) 7 Home Premium (32/64bit)
- Windows(R) 7 Professional (32/64bit)
- Windows(R) 7 Enterprise (32/64bit)
- Windows(R) 7 Ultimate (32/64bit)
- Windows(R) 8 (32/64bit)
- Windows(R) 8 Pro (32/64bit)
- Windows(R) 8 Enterprise (32/64bit)
- Windows Server(TM) 2012 Standard (64bit)
- Windows Server(TM) 2012 R2 Standard (64bit)
- Windows(R) 8.1 (32/64bit)
- Windows(R) 8.1 Pro (32/64bit)
- Windows(R) 8.1 Enterprise (32/64bit)

OS that supports linking with SharePoint(TM) Server

- Windows Server(TM) 2003 R2, Standard Edition (SP2 or later)
- Windows Server(TM) 2003 R2, Standard x64 Edition (SP2 or later)
- Windows Server(TM) 2008 Standard (32/64bit)
- Windows Server(TM) 2008 R2 Standard (64bit)

SharePoint(TM) Server refers to:

- Microsoft(R) Office SharePoint(TM) Portal Server 2003
- Microsoft(R) Office SharePoint(TM) Server 2007
- Microsoft(R) SharePoint(TM) Server 2010

2. Installation

- * Be sure to log on as a user with Administrator privileges to install the program.
- * When the User Account Control dialog box appears during installation, click the [Continue] button.
- * Be sure to select a local folder as the installation folder.
- * Do not install the program directly under the root folder. If the program is installed directly under the root folder, it may not work properly. Install the program in a folder other than the root folder.
- * Do not use the following characters for the installation folder name. If any of the characters below is used, the program may not work properly.
/ ; : , . * ? " < > |
- * To use SharePoint(TM) Server, you need to install Scan to Microsoft SharePoint first.
- * To use SharePoint(TM) Server, you first need to install the server module for ScandAll PRO in

the server where SharePoint(TM) Server is running.

Execute "ScandAllPROSrv.exe" under \ScandAll\ScandAll\ in the Setup DVD-ROM.

- * A warning message may appear during the installation of ScandAll PRO if a resident program such as anti-virus software is running.

3. Uninstallation

- * Be sure to log on as a user with Administrator privileges to uninstall the program.
- * When the User Account Control dialog box appears during uninstallation, perform one of the following:
 - If you are logged on as a user with "administrator" privileges, click the [Continue] button.
 - If you are logged on as a user without "administrator" privileges, select a user with "administrator" privileges first, enter the password, and then click the [OK] button.
- * Uninstall Microsoft .NET Framework after uninstalling Scan to Microsoft SharePoint.

4. Notes

1) About the operating environment

- This software does not guarantee reliable operations if used with Terminal Service Client or Remote Desktop Connection Client.
- To use this software, set the display to High Color or higher mode. If 256 or less color mode is selected, the display may be incorrect.

2) About supported drivers

- This software supports fi-series scanners, but users must install supported scanner drivers separately.
- This software supports ISIS-compliant, TWAIN, and Kofax VRS (Virtual ReScan), but does not support WIA (Microsoft Windows Image Acquisition).
- The scanner settings may need be reconfigured once the scanner driver has been upgraded.

3) About Image Processing Software Option (Trial)

- If the trial version of Image Processing Software Option is installed, a notification about its trial period may appear when you start ScandAll PRO or attempt to start a scan, etc. If you wish to continue using the software, please purchase the full product version.

The following component is used in this product.

libtiff

Copyright (c) 1988-1997 Sam Leffler

Copyright (c) 1991-1997 Silicon Graphics, Inc.

Permission to use, copy, modify, distribute, and sell this software and its documentation for any purpose is hereby granted without fee, provided that (i) the above copyright notices and this permission notice appear in all copies of the software and related documentation, and (ii) the names of Sam Leffler and Silicon Graphics may not be used in any advertising or publicity relating to the software without the specific, prior written permission of Sam Leffler and Silicon Graphics.

THE SOFTWARE IS PROVIDED "AS-IS" AND WITHOUT WARRANTY OF ANY KIND, EXPRESS, IMPLIED OR OTHERWISE, INCLUDING WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

IN NO EVENT SHALL SAM LEFFLER OR SILICON GRAPHICS BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER OR NOT ADVISED OF THE POSSIBILITY OF DAMAGE, AND ON ANY THEORY OF LIABILITY, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

=====

- Microsoft, Windows, Windows Vista, Windows Server and SharePoint are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Intel and Intel Core are trademarks or registered trademarks of Intel Corporation in the United States and other countries.
- ISIS is a registered trademark of EMC Corporation of the United States.
- Kofax and VRS are trademarks or registered trademarks of Kofax, Inc.
- Adobe and Acrobat are either registered trademarks or trade names of Adobe Systems Incorporated in the United States and/or other countries.
- Other company names and product names are the registered trademarks or trademarks of the respective companies.